

TriplexConnect

TriplexConnect Device is for use on 12VDC Only


The **TriplexConnect** is a cord interface, which when connected to the machines on your Sporting Clays course, allows you to control **TWO** machines VIA one 3 wire cord connected to a Universal Pickle, 3 button release.

You simply run a 3 wire extension cord, available at any home supply store, from the "**Universal Pickle**" at your shooting station to the first machine, then a 2nd 3 wire extension cord to the second machine.

With the **TriplexConnect** device mounted on your machines, you no longer need to run a cord from each machine to the shooting station, and have two different release buttons.

By connecting the two **TriplexConnect** devices to the "**Universal Pickle**" you have independent control of each machine, plus true pair doubles. This is all accomplished without "Cross Talk" between the machines or the need to add diodes to eliminate the "Cross Talk".

The **TriplexConnect** is a potted, all weather device, integrated to a sturdy aluminum mounting plate. The plate has 4 holes to secure the TriplexConnect device to your machine.



The Three electrical connectors are chosen to accommodate standard 3 wire extension cords available from any home supply store, 14ga or 16ga recommended.

NOTE: The **TriplexConnect** is not designed for use with 120VAC or 220VAC power sources

The **TriplexConnect** includes a PIGTAIL, which plugs into one of the leads labeled:

Machine #1

Machine #2

Then connect to the release cord of the machine on which it is mounted.

You can choose which button the machine will respond to by which lead, Machine #1 or Machine #2, you plug the "PIGTAIL" into.

The following components are recommended for one station, with two machines:

One "Universal Pickle" or "Universal Pickle-8100 Assembly"

2 each **TriplexConnect** devices.

2 each extension cords (customer supplied)

Refer to the following illustrations for typical applications:

